


DRIFT WALL CONTROL



CON-DRW4

- ① **Reverse & Increase Fan Speed**
To increase the fan speed, press the button once for each speed level (Speed 1-6). Press and hold the button for 5 seconds for reverse direction.
- ② **Forward & Reduce Fan Speed**
To reduce the fan speed, press the button once for each speed level (Speed 6–1). Press and hold the button for 5 seconds for forward direction.
- ③ **Light Control**
Use the switch to turn the light ON or OFF. Each time the light is switched OFF and ON, the color temperature will change: 2700K → 3400K → 5000K. If the light is off for 10 seconds, it will start with last colour temperature setting.
- ④ **Fan Power**
Use the switch to turn the fan ON or OFF.

| Product SKU | Ceiling Fan | Number of Fans | Input Voltage | Lead Wires |
|-------------|-------------|-----------------------|---------------|------------|
| CON-DRW4-1 | Drift | Controls 1 Fan | 120V | 6" |
| CON-DRW4-4 | Drift | Controls up to 4 Fans | 120V | 6" |

Included in Box:

- Wall Mounted Bracket
- Switch Plate
- Control Panel
- Hardware
- Fan Receiver

